

BREAKDOWN URINE DIGESTER

FRESH CLOVER TEA SCENT WITH ENZYME CLEANING ACTION!

DESCRIPTION

Breakdown Urine Digester is a concentrated water-soluble enzyme and deodorizer specially formulated to breakdown and eliminate urine and all other organic matter at the source. Perfect for deodorizing restrooms, carpets and drains.



FEATURES & BENEFITS

- Enzyme-powered odor removal
- Fresh Clover Tea scent
- Multi-surface use
- Easy application

RECOMMENDED USES

- Restroom Odors
- Multi-Surface Odors
- Carpet and Upholstery Odors
- Septic or Holding Tanks
- Plumbing Maintenance
- Grease Traps

DIRECTIONS

- RESTROOM ODORS:** Spray full strength **Breakdown Urine Digester** on or around toilets and urinals. Spray grouting and allow to soak in and air dry. Dilute 16 oz. (473mL) of **Breakdown Urine Digester** to 1 gallon (3.785 L) of water for mopping applications.
- MULTI-SURFACE ODORS:** Dilute 8 oz. (237 mL) of **Breakdown Urine Digester** to 1 gallon (3.785 L) of water, for use on all water-safe surfaces.
- CARPET AND UPHOLSTERY ODORS:** Pretest for color fastness. Clean area with wet sponge. Dilute 1 oz. (30 mL) of **Breakdown Urine Digester** with 2 oz. (60 mL) of warm water. Saturate surface with mixed solution and brush in well. For older, more difficult odors, it may be necessary to repeat procedure or inject into carpet backing.

PROPERTIES	
Color	Blue
Fragrance	Pleasant
Concentrate	No
pH	7.0 - 9.0
Density	8.4
VOC Content	0.02
PACKAGING	
12 x 1 qt	3021-12
1 x 55 gal	3021-55
DOT	
Not regulated	

For industrial use only. Refer to the product's Safety Data Sheet (SDS) for complete safety, handling, and first aid information.

BREAKDOWN URINE DIGESTER

FRESH CLOVER TEA SCENT WITH ENZYME CLEANING ACTION!

DIRECTIONS CONTINUED

4. **SEPTIC OR HOLDING TANKS:** Pour 1 quart (1 liter) of *Breakdown Urine Digester* for initial treatment of a 500 gal. (1,893L) tank. Thereafter, use 1 pint. (473mL) per week.
5. **PLUMBING MAINTENANCE:** For slow drains, pour or inject 4-6 oz. (118-177mL) of *Breakdown Urine Digester* per week into drain.
6. **GREASE TRAPS:** Pour or inject 1 quart. (1 liter) of *Breakdown Urine Digester* into average grease trap for initial treatment. Thereafter, treat trap with 6-8 oz. (177-237mL) per day.

For industrial use only. Refer to the product's Safety Data Sheet (SDS) for complete safety, handling, and first aid information.